My Naturewatch Camera doesn't work : (Replace the power Is the red light on the camera module on? Make sure the 5V power - No \longrightarrow source USB cable. source and cable are rated to at least 1A. The camera connector on the Pi Zero is very fiddly. Make sure you seat the camera into the Make sure your camera ribbon connector fully and make Yes Yes is seated in the sure the plastic squeezer is connector properly. clicked in fully. If you've broken your connector, you may still be able to get your camera working. Click here for tips on fixing the connector. The image file could have been loaded to the SD card Does the camera's WiFi 5. incorrectly. The SD card could Reflash / replace the Can you see a live preview of the camera? - No \longrightarrow be corrupt. Make sure your SD SD card. card is 16GB Class 10 or better 5 minutes? Can you quality. Yes Yes Replace the power Make sure the 5V power source 6. Are your sure the Is the preview frozen on the camera? - No \longrightarrow -Yes \rightarrow source or USB cable. Is and cable are rated to atleast 1A. address is typed in correctly? it still frozen? Yes Yes No To check if you're affected by a bug, Is the issue the same click here. Make sure your device has when trying to access JavaScript enabled and that the page with another you're not using a Hooray! Your camera is device? strict firewall. working:)